

DWZ series Updater

Operating Manual for Windows XP

Contents

1. Summary	3
2. Preparing	3
3. Install procedure	4
3-1. Folder structure	4
3-2. Installation	4
3.2.1 Installing the Updater	4
3.2.2 Installing the USB Driver	7
4. Update procedure	10
5. Confirmation after updating	12

1. Summary

This manual is a procedure of firmware update of ZTX-B01, ZTX-M01, ZTX-B02RC, ZTX-M02RC, ZRX-C30, ZRX-HR50 and ZRX-HR70.

This manual is explained for procedure of ZRX-HR50, but other equipment is same procedure as ZRX-HR50.

2. Preparation

< Software >

Obtain the Updater file depending on the unit to be updated.

< Others >

Personal Computer

OS : Windows XP SP3, Windows Vista, Windows 7 or Windows 8

USB cable: Type A – Type Micro B (P/N 1-835-226-11 or 1-836-906-11)




3. Install procedure

Install Updater and USB driver to PC.

This item explains about ZRX-HR50, but other equipment is same procedure as ZRX-HR50.

<3.1 Folder Structure>


The folder structure is shown below.



<3.2 Installation>


3.2.1 Installing the Updater

A) Double click ¥ZRX-HR50_Updater_Setup_for_Ver_1_100¥setup.exe.



B) When Screen 1 is displayed, click [Accept] and proceed to procedure C).
When Screen 2 is displayed, proceed to step D).


[Screen 1]



[Screen 2]




C) .NET Framework 2.0 required to operate the Updater is being installed.




Once the installation of the .NET Framework 2.0 is completed, the following screen is displayed. Proceed to step D).





D) Click [Next>]




E) Click [Next>]



F) Installation will start when [Next >] is clicked.



G) When the following screen is displayed, click [Close]. This completes the setup of the Updater.




3.2.2 Installing the USB Driver

Installation of the USB driver is required when connecting the unit for the first time.
It is not required anymore if it is installed once.


- A) Turn on the power of ZRX-HR50.
- B) Connect PC (update software is installed) and ZRX-HR50 via USB cable.
(Please refer to “4. Install procedure”)
At this time, indicators and displays of ZRX-HR50 except the power supply LED will turn off, but this is not a malfunction.
- C) A balloon indicating a new unit is connected is displayed on the task bar of the PC, and connection wizard will start up. Select “No, not this time” and click [Next >].



- D) Select “Install from a list or specific location (Advanced)” and click [Next >].




E) Click [Browse].




F) Select

¥ZRX-HR50_Updater_Setup_for_Ver_1_100¥USB_Driver¥for_32bit from the folder tree and click [OK].




G) Click [Next >].




H) Installation will start when [Continue Anyway] is clicked.



I) When the following screen is displayed during the installation, click [Browse] same as in steps D) and E), and specify the folder of the USB driver from the folder tree. Installation will continue when [OK] is clicked after specifying. When it is not displayed, continue to the next step without doing anything.




J) When the following screen is displayed, click [Finish]. This completes the installation of the USB driver.




5. Update procedure

This item explains about ZRX-HR50, but other equipment is same procedure as ZRX-HR50.


- A) Turn on the power of ZRX-HR50.
- B) Connect the PC with the ZRX-HR50 using a USB cable.
At this time, indicators and displays of ZRX-HR50 except the power supply LED will turn off, but this is not a malfunction.
- C) Click [All Programs] -> [Sony DWZ Flash Write Tool] -> [ZRX-HR50 Ver. 1.100 Updater] in the Start menu.




- D) Click [Write].




- E) Update will start by clicking on [Yes].




- F) Progress as shown in the following screen is displayed during the update.



G) A dialog is displayed once the update is completed, so click [OK].




H) This completes the update. Click [Exit] to exit from the Updater.



I) Disconnect the USB cable from the ZRX-HR50, and turn off the power of the set.

* When the update fails

Following screen is displayed when the update fails. In such cases, click [Quit], and then restart the Updater to execute the update.



6. Confirmation after updating


This item explains about ZRX-HR50, but other equipment is same procedure as ZRX-HR50.

A) Turn on the power of ZRX-HR50.


B) Connect the PC with the ZRX-HR50 using a USB cable.

At this time, indicators and displays of ZRX-HR50 except the power supply LED will turn off, but this is not a malfunction.


C) Click [All Programs] -> [Sony DWZ Flash Write Tool] -> [ZRX-HR50 Ver. 1.100 Updater] in the Start menu.




D) Click [Read Version]



E) Software version will be appeared. After you confirm the software version, click [OK].



F) Click [Exit]



G) Pull off the USB cable from ZRX-HR50, and turn off the power of ZRX-HR50.